

1. WARNING - Turn off the power. Before starting the installation, locate the circuit breaker in the electrical circuit panel and	LIGHTWAY INDUSTRIES			
switch the circuit off. Turning off the light is not sufficient to prevent electrical shock.	VALENCIA CA 91355			
2. Remove the old fixture. If you are replacing an existing fixture, remove all components of the old fixture (cover, mounting plate,				
etc), remove the old wire connectors, and expose the supply wiring from the electrical box.	INSTAL	LATION 🔤	<sup>вү</sup> М.	
3. <b>Connect the wires</b> . Use a wire stripper to remove the protective coating of the wires. Connect the grounding wire (green or bare	INSTRU		ROA	4
copper wire) from the electrical box to the green wire of the fixture. Connect the white wire from the electrical box to the white	DESCRIPTION CMDB-INSTL-INSTR			
wire of the fixture. Connect the black wire from the electrical box to the black wire(s) of the fixture.				
4. <b>IMPORTANT</b> . Use only UL Listed connectors and tape to complete the installation. Carefully read and follow any additional				
installation instructions provided in this shoot		PART NUMBER	R	.EV
	4/29/2019	62-237-00-	-R	0