



SLICED ASSEMBLY VIEW



- NOTE: TO VERIFY THE COTTER PIN WILL BE INSERTED, THE HOLES IN THE J-BOX MAY NEED TO BE ADJUSTED CAREFULLY TO ENSURE THE CANOPY IS FLUSH WITH THE CEILING.
1. SECURELY THREAD THE TUBES TO THE COUPLINGS SHOWN BELOW.
 2. ALIGN & INSERT THE CANOPY ON TOP OF THE 4 TUBES.
 3. ALIGN & INSERT THE SUPPORT PLATE ON TOP OF THE CANOPY AND TUBES.
 4. INSERT THE INTERNAL LOCK WASHER AROUND THE THREAD OF THE TUBES.
 5. THREAD AND TIGHTEN THE HEXAGONAL NUTS TO THE TUBES.
 7. INSERT THE COTTER PIN TO THE 2.5" NIPPLE HOLE AND BEND THE ENDS OUTWARDS.
 8. THREAD THE (2) #8 $\frac{5}{8}$ SCREWS TO THE J-BOX.
 9. LIFT UP THE ASSEMBLED FIXTURE AND ALIGN THE BIG CANOPY HOLE TO THE 2.5" NIPPLE (AT THIS POINT IT IS FIRMLY ATTACHED TO THE J-BOX.)
 10. INSERT THE 2.5" \varnothing WASHER.
 11. INSERT THE COTTER PIN TO THE 2.5" NIPPLE AND BEND THE ENDS OUTWARDS. AT THIS POINT THE FIXTURE SHOULD BE HELD BY THE COTTER PIN.
 12. ALIGN & INSERT THE SMALL 3" \varnothing CANOPY TO THE 2.5" NIPPLE.
 13. THREAD AND TIGHTEN THE KNOB TO SECURE THE SMALLER CANOPY.



INSTALLATION INSTRUCTIONS

1. WARNING - BEFORE STARTING THE INSTALLATION, DISCONNECT THE POWER BY TURNING OFF THE CIRCUIT BREAKER OR REMOVING THE FUSE BOX. TURNING OFF THE POWER BY TURNING OFF THE LIGHT SWITCH IS NOT SUFFICIENT TO PREVENT ELECTRICAL SHOCK.

2. IF YOU ARE REPLACING AN EXISTING FIXTURE, DISCONNECT AND REMOVE THE OLD FIXTURE. EXPOSE THE SUPPLY WIRING FROM THE ELECTRICAL BOX.

3. MAKE ELECTRICAL CONNECTIONS BY CONNECTING THE GROUNDING WIRE (GREEN OR BARE COPPER) FROM THE SUPPLY CIRCUIT TO THE GREEN COLORED WIRE FROM THE FIXTURE. CONNECT THE WHITE WIRE(S) FROM THE FIXTURE TO THE WHITE WIRE OF THE SUPPLY CIRCUIT. CONNECT THE BLACK WIRE(S) FROM THE FIXTURE TO THE BLACK WIRES OF THE SUPPLY CIRCUIT, USE THE UL LISTED WIRE CONNECTORS (BY OTHERS). SECURE THE WIRE CONNECTORS WITH UL LISTED ELECTRICAL TAPE (BY OTHERS).

DO NOT SCALE DRAWING

TOLERANCES		LIGHTWAY INDUSTRIES	
DECIMALS			
.X \pm .1		DESCRIPTION	
.XX \pm .01			
.XXX \pm .005			
ANGLES		RERH	
.X \pm 1°			
BY	DATE	PART NUMBER	REV
RobertoL	5/8/2013	62-132-01	0